

Aztech Modemlerde port acmak ;

Adres çubuğuna <http://192.168.1.1/> yazın ve klavyenin Enter tuşuna basın.

Size Kullanıcı Adı (User Name) ve Şifre (Password) soracaktır. Değiştirmediyse default değerlerini modemizin kullanım klavuzundan (manuel) bulacağınız değerleri girin. Eğer kullanım klavuzunuz (manuel) yoksa Default değerleri ;

User Name : admin

Password : bos birakin enterlayın.

Ekran n solundaki pencereden Advanced Configuration alt ndaki port forwarding tıklayın.

Bu menüyü TCP:4662 portu için aşağıdaki gibi doldurun ve Add This Setting tıklayın.

Quick Start

- Login Status
- Login Settings
- Diagnostic Test

Status

- Overall Status
- LAN Status
- ATM Status
- PPP Status
- TCP Status
- System Log

Advanced Configurations

- LAN & DHCP
- NAT
- Port Forwarding
- Admin Password
- Firmware Update
- Save Settings

To Admin Mode

Port Forwarding

Add new rule:

ID	Public Port	Private Port	Port Type	Host IP Address	
1	4662	4662	☒ TCP ☐ UDP	192.168.1.2 PCnizin IP nosu	Add This Setting

Existing rules:

ID	Public Port	Private Port	Port Type	Host IP Address
----	-------------	--------------	-----------	-----------------

Please ensure to click [Save Settings](#) for settings to take effect.

Aynı İşlemleri UDP Portu icinde tekrarlayın.

Soldaki pencereden Save Settings tıklayarak yaptıklarınızı kaydedin.