


## DATRON RTA230 Adsl Modemlerde Port Açmak

Adres çubuğuna <http://192.168.1.1/> yazın ve klavyenin Enter tuşuna basın.




Kullanıcı Adı ve Şifre soracaktır. Değiştirmediyse default değerleri.

Kullanıcı Adı : root

Şifre : root

Çıkış menüsünden önce Advanced, sonra sırasıyla Virtual Server ve Port Forwarding tıklayın. Aşağıdaki gibi Port Forwarding menüsü çıkacaktır. Bu menüden Add tıklayın.



Aşağıdaki Add New Port Forwarding Rule menüsü çıkacaktır.

ADSL Router - Microsoft Internet Explorer

Dosya Düzen Görünüm Sık Kullanılanlar Araçlar Yardım

Adres http://192.168.1.1/main.html

**DSL** Quick Start | Status | Advanced | Diagnostics | Management

Language: English

Local Network  
Internet  
IP Routing  
DNS Server  
Virtual Server  
Port Forwarding  
Port Triggering  
DMZ Host  
Dynamic DNS  
Firewall  
IGMP Proxy

### Add New Port Forwarding Rule

Application Name:

Pre-defined:

User defined:

Forwarded to Internet Host IP Address:

By using the rules:

Protocol	External Packet		Forward to Internet Host	
	Port Start	Port End	Port Start	Port End
TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
TCP	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Aşağıdaki resimde gösterildiği gibi eMulenin kullandığı TCP:4662 portu PCnizin IP nosuna yönlendirin.

user defined :eMule1

Internet Host IP Address :192.168.1.2

Protocol : TCP

Port Start :4662

Port End : 4662

Port Start :4662

Port End : 4662 girin sonra Apply tıklayın.

ADSL Router - Microsoft Internet Explorer

Dosya Düzen Görünüm Sık Kullanılanlar Araçlar Yardım

Adres: http://192.168.1.1/main.html

**DSL** Quick Start | Status | Advanced | Diagnostics | Management

Language: English

Local Network  
Internet  
IP Routing  
DNS Server  
Virtual Server  
Port Forwarding  
Port Triggering  
DMZ Host  
Dynamic DNS  
Firewall  
IGMP Proxy

### Add New Port Forwarding Rule

Application Name:

Pre-defined: FTP Server

User defined: eMule1

Forwarded to Internet Host IP Address: 192.168.1.2

By using the rules:

Protocol	External Packet		Forward to Internet Host	
	Port Start	Port End	Port Start	Port End
TCP	4662	4662	4662	4662
TCP				
TCP				

Apply

Aynı Ayar'ı UDP'yi seçip tekrarlayın.

**Şimdi Roter/Modeminizin Güvenlik Duvarını (Firewall) kapatalım.**

Önce Firewall tıklayın, altından çıkan IP Filtering tıklayın ve Disable seçin, Apply tıklayın.

ADSL Router - Microsoft Internet Explorer

Doğruya Düzen Görünüm Sık Kullanılanlar Araçlar Yardım

Adres: http://192.168.1.1/main.html

Dynalink Quick Start Status Advanced Diagnostics Management

Language: English

Local Network  
Internet  
IP Routing  
DNS Server  
Virtual Server  
Firewall  
IP Filtering  
Quality of Service  
IGMP Proxy

### IP Filtering

This page allows you to specify the IP packet filtering rules to prevent the services accessed from the Internet hosts or limit the Internet access for local hosts.

IP Filtering:  Disabled  Enabled

Modeminizi yeniden baslatalım.

ADSL Router - Microsoft Internet Explorer

Doğruya Düzen Görünüm Sık Kullanılanlar Araçlar Yardım

Adres: http://192.168.1.1/main.html

Dynalink Quick Start Status Advanced Diagnostics Management

Language: English

Admin Account  
Remote Access  
Internet Time  
System Log  
Backup Config  
Update Firmware  
Reset Router

### Reset Router

This page allows you to restart your ADSL router after changing settings that require rebooting. It also allows you to reset all settings to factory default settings if you have problems with your current configuration.

Reset to factory default settings

After clicking "Reboot", please wait for 2 minutes to let the system reboot.